


III. Components List

H-CON101	x1		Battery	x1		P4	x1		P5	x1		Tire	x4	
Wheel	x4		H-M24	x4		H-S100	x1		P6	x2				
S5	x2		F1	x4		F2	x2		F3	x4		F4	x2	
Charger	x1													

